

INDASH by PANAVISE®

I-75145-201

Page 1 of 1

MOUNTING LOCATION:

Left side of climate control CR

TOOLS REQUIRED:

Hook tool

#15 Torx driver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 75145-201

MFG: INTERNATIONAL

MODELS & YEARS:

4000 Series 01-14, 7000 Series 02-13,

8000 Series 05-13, DuraStar 07-14,

TerraStar 2012-14

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 With hook tool pull off bezel that outlines the, climate control, radio, etc. Set bezel aside. There are (5) total clips.

STEP #2: Remove the (4) T-15 Torx screws that hold the climate control on. Pull out the climate control just enough to get the InDash by PanaVise over the (2) screw holes on the left side of the climate control. The PanaVise logo should be right side up. Reinstall the (2) screws on the left side of the climate control, then the right side screws.

STEP #3: Replace the bezel, securing all (5) clips.



Install InDash on these (2) holes under climate control flange

INSTALLATION IS NOW COMPLETE.
ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Prototype installed showing location
Finished Install Picture



02-19-13